

# CERAMIC TRIM COAT

## APPLICATION INSTRUCTIONS

### IMPORTANT

THIS IS A PERMANENT PRODUCT. FOLLOW ALL INSTRUCTIONS!



TAKE A "BEFORE" PHOTO OF YOUR TRIM

1. Wash and dry surface thoroughly, using a non-wax containing detergent such as blue Dawn® dish soap.
2. **IMPORTANT:** Must be applied to a completely dry surface. Ideal environmental conditions for application are between 60°F and 75°F.
3. **TIP:** Open and close doors, trunk and hood several times to free any trapped water. If product comes in contact with paint or glass, remove immediately with a clean dry cloth.
4. Wearing provided gloves, open one (1) pack and wipe trim surface in overlapping passes to ensure full coverage.
5. Rotate wipe as needed, ensuring you use all the surfaces of the wipe. Move to a new pack when wipe becomes dry or soiled.
6. After application, allow a minimum of 1 hour before driving or exposure to moisture.



TAKE AN "AFTER" PHOTO OF YOUR TRIM



SUBMIT YOUR "BEFORE & AFTER" PHOTOS  
TO INSTAGRAM #CERAKOTEAUTOMOTIVE

**ALWAYS WEAR CHEMICAL RESISTANT  
GLOVES WHILE HANDLING.**



Application Videos and Tips:  
[CerakoteCeramics.com](https://www.cerakoteceramics.com)

Call for help or questions:  
866.774.7628

**DANGER:** Keep out of reach of children. Eye & skin irritant, flammable liquid & harmful vapor. **Read all cautions and instructions prior to use.** For complete SDS and guarantee details visit [cerakoteceramics.com](https://www.cerakoteceramics.com)

# CERAMIC TRIM COAT

## APPLICATION INSTRUCTIONS

# IMPORTANT!

**THIS IS A PERMANENT PRODUCT INTENDED TO RESTORE **FADED, UNTREATED, UNPAINTED** EXTERIOR TRIM. NOT FOR USE ON INTERIOR TRIM, NEW TRIM, OR PLASTIC WINDOW TRIM. PLEASE FOLLOW ALL INSTRUCTIONS!**

**ALWAYS WEAR CHEMICAL RESISTANT GLOVES WHILE HANDLING.**

SCAN FOR  
INSTRUCTIONAL VIDEO



**CERAKOTE<sup>®</sup>**  
CERAMIC COATINGS

**NEED MORE HELP?**



866.774.7628

[www.cerakoteceramics.com](http://www.cerakoteceramics.com)

V01052024